

X-Shot Dual

Information:

The X-Shot Dual Dart and Disc Blaster contains a dual ammo system that allows the Dual to shoot both darts and discs. Dual may come with X-Shot target for added value. For more information on the X-Shot Dual and other items in the X-Shot Arsenal, visit www.x-shot.com

Instructions:

1. Load gun with ammo (darts, discs, or both).
2. Pull back the handle to lock and load.
3. Pull the trigger to shoot (perhaps at the X-Shot target).
4. Store your discs and darts in the designated storage compartments.

Warnings:

The X-Shot Dual Dart and Disc Blaster was designed for children ages 8 and up. This product contains small parts and is not suitable for children under the age of 3 years. Do not aim at eyes or face. To ensure safety, only use darts designed for this product. Dart blaster and darts should not be modified.

This product could be mistaken for an actual firearm by law enforcement officers and others. It may be a crime to alter any state or federal required markings and coloration in an attempt to make the product appear more realistic. It may be a crime to brandish and display the product in public.

