

X-Shot XCESS

Information:

The X-Shot Xcess dart blaster features a dual ammo system that shoots both darts and discs. The rotating, double barrel dart storage chamber holds up to 6 darts in each barrel.

Instructions:

1. To Blast Darts

- Pull back the pump handle until you hear a click and the barrel has rotated.
- Fully release the pump handle and pull the trigger to blast your dart.

2. To Blast Discs

- Rotate the barrel to disengage the dart blasting function.
- Pull back the pump handle until you hear a click and the barrel has rotated.
- Fully release the pump handle and pull the trigger to blast your disc.

Warnings:

The X-Shot Xcess was designed for children ages 8 and up. This product contains small parts and is not suitable for children under the age of 3 years. Do not aim at eyes or face. To ensure safety, only use darts designed for this product. Dart blaster and darts should not be modified.

This product could be mistaken for an actual firearm by law enforcement officers and others. It may be a crime to alter any state or federal required markings and coloration in an attempt to make the product appear more realistic. It may be a crime to brandish and display the product in public.

